



AxeShield Installation Instructions

First, use a clothing iron set on "Satin" to take the packaging lines out. Spraying a little water on the AxeShield as you Iron it is a HUGE help.

Next, lay the AxeShield on top of the instrument when it's in the case with the Tabs facing you.

Mark the position of each Tab with soap or chalk on the case edge.

Use a scissor, narrow knife or screwdriver to separate the case lining from the case wall where you marked the tab positions...going down about 1 1/2" to 2" to create a slot for each Tab.

Insert the Tabs into the slots you just created.